

Here is the variable list before I run the script. As you can see no Nest variables.

Variable	Type	Size	Value
\$CameraHorizontalQuadrant_2	String	5	"Right"
\$CameraHorizontalQuadrant_3	String	5	"Right"
\$CameraIsTracking	Number		1
\$CameraObjectCenterX	Number		161
\$CameraObjectCenterX_1	Number		11
\$CameraObjectCenterX_2	Number		216
\$CameraObjectCenterX_3	Number		213
\$CameraObjectCenterY	Number		206
\$CameraObjectCenterY_1	Number		139
\$CameraObjectCenterY_2	Number		206
\$CameraObjectCenterY_3	Number		186
\$CameraObjectCount	Number		0
\$CameraObjectHeight	Number		68
\$CameraObjectHeight_1	Number		41
\$CameraObjectHeight_2	Number		14
\$CameraObjectHeight_3	Number		12
\$CameraObjectWidth	Number		102
\$CameraObjectWidth_1	Number		16
\$CameraObjectWidth_2	Number		19
\$CameraObjectWidth_3	Number		17
\$CameraObjectX	Number		110
\$CameraObjectX_1	Number		3
\$CameraObjectX_2	Number		207
\$CameraObjectX_3	Number		205
\$CameraObjectY	Number		172
\$CameraObjectY_1	Number		119
\$CameraObjectY_2	Number		199
\$CameraObjectY_3	Number		180
\$CameraTrackingType	String	6	"Moti...
\$CameraTrackingType_1	String	6	"Moti...
\$CameraTrackingType_2	String	6	"Moti...
\$CameraTrackingType_3	String	6	"Moti...
\$CameraVerticalQuadrant	String	6	"Bott...
\$CameraVerticalQuadrant_1	String	6	"Bott...
\$CameraVerticalQuadrant_2	String	6	"Bott...
\$CameraVerticalQuadrant_3	String	6	"Bott...
\$Direction	String	4	"Stop"

Now the Nest variables after I run the script.

\$Direction	String	4	"Stop"
\$EZBPlayingAudio	Number		0
\$nest_humidity	Number		50
\$nest_is_online	Number		1
\$nest_target_temp_c	Number		26.5
\$nest_target_temp_f	Number		80
\$nest_target_temp_high_c	Number		24
\$nest_target_temp_high_f	Number		75
\$nest_target_temp_low_c	Number		20
\$nest_target_temp_low_f	Number		68
\$nest_temp_c	Number		24.5
\$nest_temp_f	Number		76
\$nest_temp_high_c	Number		26.5
\$nest_temp_high_f	Number		80
\$nest_temp_low_c	Number		4
\$nest_temp_low_f	Number		40

None correspond to the Temp within the house nor the target temperature.

Also something I've noticed. If you the Nest control to your project, it puts a little box on the screen. Here is mine:



It always shows Last update as N/A.

I have started EzB in admin mode, just to be sure, still the same results.

I don't believe I am getting data from Nest, even though I have successfully configured my account.