

SYNTHIAM

synthiam.com

How to choose correct battery(s).

Given the wide range of actuators and electronics which go into a robot, choosing the right battery may not be an easy task. This tutorial guides you through the thought processes involved in choosing one or more batteries for your robot.

Last Updated: 10/15/2015

5 Choosing out of Uni or Multiple battery.

How do you know if you need **multiple batteries**? Check the nominal voltage of each of the products you selected:

1. Electronics (microcontroller, motor controller power etc) usually operate at 9V-12V. Some operate at low as 3.3V and 5V. 2. Actuators (DC gear motors, stepper motors, servos etc) usually operate at 6V to 12V. A few operate as low as 3V 3. Sensors usually operate 5V

Based on the ranges above, it's easy to see how, when selecting optimal components for your project, that the voltage range may differ for each type of component. Fortunately most microcontrollers has a built-in voltage regulator which provides 5V to the I/O pins, so you don't need a dedicated 5V battery. Should you choose a normal microcontroller, it's likely that the voltage range is 9V to 12V. Operating a normal hobby servo motor (rated at 4.8V to 6V) from a 9V to 12V battery would quickly burn it. What to do? The easiest option would be to use a smaller 12V battery for the microcontroller, and a larger 6V battery for the servos.

Continuing the example above, where we chose a 12V microcontroller and 4.8V to 6V hobby servos, we have the option of using one (larger) 6V battery pack and a step-up voltage regulator. A voltage regulator does exactly as the name implies; it regulates the voltage. In our case we would need one which can accept 6V input and step it up to 12V.

Choosing a lower motor voltage does not automatically mean the list of motors available to you will be low power. However, a high voltage motor (36V, 48V, 60V) tends to be reserved for large DC motors. The second approach is to first select the ideal motor and design your robot's electronics system around the indicated nominal voltage. Both approaches have their advantages and disadvantages and it is up to you to choose which you prefer.

Voltage dividers allow you to power electromechanical devices at different voltages. Voltage dividers are purely electrical devices with no programming involved. If you do not want to use voltage dividers, most electronics operate at 5 to 9V, so choosing either 6 or 9V as your robot's supply voltage is the best choice (never assume an electronic device operates at 6 or 9V: you always need to read the supply voltage specifications for each electronic component). The other option is to use two different power supplies: one for the motors and another (smaller one) for the electronics.

Should you wish to operate your robot at 9V, you can often still choose a 12V motor, though you must keep in mind the rpm will be less than that listed (estimated as a fraction of the nominal value) and the motor efficiency will be slightly reduced.

[feature] This tutorial has been borrowed from Coleman Benson's post at [Robot Shop](#) [/feature]

5 Choosing right type of battery

Robots using servo motors (legged robots or robotic arms) tend to operate at 4.8V (4x AA NiMh cells) or 6V (5x NiMh AA cells). You can use a fairly inexpensive voltage regulator to power the microcontroller, increasing the voltage from 6V to 9V.

Small to medium mobile robots often use a 6V, 9V or 12V NiMh battery pack, the choice of which depends on the nominal voltage of the drive motors. If the robot includes one or more servo motors (for a pan/tilt for example), the microcontroller can usually provide enough current from a 5V digital pin. If your microcontroller operates at 9V and you want to use 6V motors, you might consider a two battery solution.

Medium sized mobile robots tend to use one 12V battery; lead acid or single NiMh battery pack (or an 11.1V LiPo battery if weight is an issue). Large robots use 12V or 24V from one or more lead acid battery packs.

Standard battery voltages are: 1.2V: one rechargeable NiMh AA or AAA battery (unless you want a really small robot, one cell does not do much)

1.5V: one Alkaline AA or AAA battery (disadvantage of not being rechargeable and can't do much on its own)

2.4v: two rechargeable AA or AAA batteries; still can't do much on their own, even for small robots

3V: two alkaline AA or AAA batteries; most microcontrollers cannot operate at this voltage, let alone most actuators.

3.6V: three rechargeable NiMh AA or AAA batteries; this is usually the minimum voltage to run certain microcontrollers

3.7V: one LiPo battery; this is close enough to 3.6V and is the minimum to run certain microcontrollers

4.5V: three alkaline AA or AAA batteries; why even consider non-rechargeable in robotics?

4.8V: four AA or AAA together provide the minimum voltage to operate a standard hobby servo motor. These can be either as individual cells or as a single rechargeable battery pack.

6V: four AA or AAA alkaline batteries, five rechargeable NiMh cells or one 6V rechargeable lead acid pack; this is the maximum (and ideal) voltage most hobby servos can handle. Use these if your servos need a bit more power.

7.2V: six AA or AAA rechargeable NiMh batteries is perfect for 7.2V DC gear motors. These are usually in a battery pack rather than as individual cells and you will need a more specific NiMh battery pack charger.

7.4V: two LiPo cells can often power a microcontroller and works great for 7.2V DC gear motors. Unfortunately it's too high for most hobby servo motors.

7.5V: five alkaline AA or AAA: almost never used because itâ€™s simply too many single-use batteries.

8.4V: 7x NiMh AA batteries (hard to find chargers for 7xAAA NiMh batteries). This is also not used much because it means charging 7 batteries at the same time.

9V: 6x Alkaline batteries, one 9V (NiMh or Alkaline) battery or one 9V lead acid batteru: please avoid using 6x alkaline for the sake of the environment. A 9V single cell rectangular battery is often used to power the microcontroller in dual battery configurations. 9V lead acid batteries are a bit harder to find and although they are quite heavy, are fairly inexpensive and high capacity.

9.6V: 7x NiMh cells, usually in a battery pack configuration. This is good for motors which operate at 9V, and also for microcontrollers (most can operate above 9V).

11.1V: three LiPo batteries produces almost 12V and is much lighter than 10x 1.2V cells or a 12V lead acid battery pack. You need a specific LiPo charger capable of charging 3 cell LiPo packs.

12V: 10x 1.2V cells (always configured as one NiMh battery pack) or one 12V rechargeable lead acid battery pack. 12V is ideal for a variety of DC gear motors and most microcontrollers.

Anything above 12V is usually reserved for very large robots. If you have a 14.4V LiPo or 18V NiMh pack from a cordless drill, keep in mind that finding motors which operate at these voltages is not easy.

[feature] This tutorial has been borrowed from Coleman Benson's post at [Robot Shop](#) [/feature]

NiMh: This is by far the most common type of battery used in mobile robots. NiMh batteries are rechargeable and their value (price / capacity / weight) is hard to beat. There is almost no memory effect, meaning every charge should bring the battery up to full capacity.

NiCd: These batteries are slowly disappearing because of their memory effect: if you don't discharge the battery properly and then recharge it to full capacity, you lose part of the capacity each time.

Alkaline: These are the least expensive batteries in the short term, and provide a higher voltage than NiMh, but are not great for the environment, and you constantly need to buy replacements.

Lead Acid: Still the cheapest option for high capacity, lead acid is usually reserved for medium sized robots because of their incredibly high weight.

LiPo: These are fast becoming the most popular type of battery because of their light weight, high discharge rates and relatively good capacity, except the voltages increase in increments of 3.7V, so you need to plan to use LiPo before selecting your electronics and actuators.

[feature] This tutorial has been borrowed from Coleman Benson's post at [Robot Shop](#) [/feature]

NOMINAL VOLTAGE

A motor's nominal voltage is the voltage at which the motor provides the best power output to efficiency ratio (rather than highest efficiency or highest power output). Operating a motor at the nominal voltage also helps to guarantee a long useful life.

[feature] This tutorial has been borrowed from Coleman Benson's post at [Robot Shop](#) [/feature]

A battery's capacity determines roughly how long a battery will last at a specific voltage given a specific discharge rate. For example, if you choose a 12V, 2Ah (2000mAh) battery pack (regardless of chemistry), the battery should be able to run a 12V motor consuming 2A continuously for 1 hour. Alternatively, it can run a 12V motor consuming 1A for 2 hours, or a 12V motor consuming 0.5A for 4 hours. The rule of thumb is to divide the capacity (assuming you are running an actuator at the same voltage) by the actuator's current under normal load to get the time the motor will last.

Example 1 2x Drive Motors: 6V nominal, 1A each under normal load

1x 6V NiMh Battery Pack, 2200mAh (equivalent to 2.2Ah)

Note that the battery was chosen based on the motor's nominal voltage. Should you instead operate 6V motors from a 7.2V battery, the calculations become more difficult (use the total watt-hours divided by the total watts per hour to get an idea).

Therefore the 6V battery pack will last:

$2.2\text{Ah battery} / (2 \text{ motors} \times 1\text{A per motor}) = 1.1 \text{ hours}$

Example 2 18 servos used for a hexapod robot which operate at 6V nominal and consume 250mA under normal load*

1x 6V NiMh battery pack at 5Ah.

First, we will assume that all motors are under load at all times (i.e. worst case scenario) and therefore all 18 will be consuming a total of 4.5A

$5\text{Ah battery} / 4.5\text{A} = 1.1 \text{ hours}$

Note again that the battery was chosen based on the motor's nominal voltage.

[feature] This tutorial has been borrowed from Coleman Benson's post at [Robot Shop](#) [/feature]

DISCHARGE RATE

The continuous discharge rate of a battery is very important because if you choose a battery that cannot discharge at the required current, the robot will either not work properly or not work at all.

Example 1 You selected four 12V motors for your 4WD outdoor mobile robot. Each motor consumes 1A under normal load, and more in the case of a slope. You decide to choose a 12V, 2Ah NiMh battery pack, not caring about the continuous discharge rate. You discover that your robot stops when it encounters even the slightest obstacle or incline. Why? In this case operating all four motors consumes $\sim 4A$ while an NiMh pack can only discharge at about 1.2 times the capacity ($1.2 \times 2Ah = 2.4A$). The current draw from the motors is therefore higher than the battery can provide.

Example 2 You selected two 7.2V DC gear motors which consume 1.5A each under normal load, and up to 2A each under stressful situations. This means that the battery needs to be able to provide at least 3A normally and up to 4A safely. If you choose an NiMh pack it would need to be $4A / 1.2C = 3.3Ah$. The alternative would be to choose a LiPo pack because they can often discharge at 5C or higher, meaning you would be able to get away with a $4A / 5C = 0.8Ah$ pack. Granted the capacity is low, and you may opt for a higher capacity pack.

[feature] This tutorial has been borrowed from Coleman Benson's post at [Robot Shop](#) [/feature]